



Operation of Integrian's 2.4GHz Wireless Microphone

These simple steps will keep your wireless microphones fully charged and running smoothly.

Securing the wireless microphone to the cradle

All microphone bases have snap-in tabs to hold the mic in place while charging. To snap the mic in place:

1. Place the mic in the cradle, placing the base as far back as possible.
2. Press the mic against the back of the cradle until it clicks into place.

Charging the wireless microphone

When not in use, securely dock the wireless mic into a powered receiver/charger. Remember, turn the mic off and snap it into the cradle.

1. Make sure the car or home receiver has power. If you are charging the mic in a vehicle the vehicle should be running.
2. When docked, the "BATT" light on the receiver will illuminate red constantly, confirming proper docking and charging connections have been made.
3. Leave the wireless mic in a powered receiver / charger cradle for at least 8 hours for a full charge. NOTE: the microphone will charge with the ON/OFF switch in either position. However if the mic is left on it will use power to seek a connection with the receiver. Leave the power switch in the OFF position for optimal charging.

Synchronizing and Preparing the Microphone for Use

1. Turn the mic power switch to the ON position.
2. Dock the mic in a receiver / charger cradle.
3. Push the TALK button for at least 5 seconds, then release. The SYNC light on the receiver will flash green and the transmitter will beep to confirm synchronization. Synchronization must be performed to enable a transmitter and receiver to be used together.

We hope you find these tips helpful. For access to full documentation on Integrian's customer extranet, call Integrian Tech Support at 800.972.0373 or email support@integrian.com